


SIX-SHOT BOLT ACTION REPEATING SHOTGUN

Perfectly balanced . . . built sleek and trim for rapid, sure-firing accuracy . . . every feature for strength and safety.

J. C. Higgins Products ore Sold
Only by Seors, Raebuck and Company

A REMARKABLE GUN VALUE

This handsame repeating shatgun has a beautifully grained anepiece wolnut stock, an eosy-ta-hold pistal grip, and a finely machined trigger mechanism far a smaoth, easy pull. The receiver is allay steel to withstand high breech pressure. Independent safety slides alangside receiver for greatest passible pratectian. The barrel, of high tensile strength steel, has been praaf-tested to insure safe use with maximum lands. Gun holds six shells. Rubber recoil pad fits snugly against shaulder to help absorb shock at repeated firing. There is a nan-glore metal beod front sight.



INSTRUCTIONS FOR OPERATION AND CARE

IMPORTANT:—Befare firing this gun be sure to clean thoroughly inside of barrel of all grease or of any abstruction.

CLEANING AND LUBRICATING:—Exclusive use af Sear's ammunitian eliminates need af cleaning barrel. Shauld powder residue accumulate in barrel, it may be easily removed. Ratate balt handle upward then pull back. Rest heel af stack butt an chair ar flaor, grasp gun barrel with left hand near muzzle. Push a bross cleaning brush through borrel muzzle end. Wipe dry, all tharaughly with clath. (Make sure gun is empty af shells.)

TO MAKE GUN SAFE:—Push safety button forward until "S" an receiver is visible. This mavement of safety lacks trigger and gun connot be fired. ALWAYS tok this safety when carrying laaded gun.

TO PUT BOLT IN RECEIVER:—This gun is shipped with bolt assembly out of receiver. To assemble, loosen bolt stop screw. Push shell carrier up from underneath receiver until it is in its upward or loading position, slide bolt into receiver, with bolt handle up. Push bolt forward until carrier drops and turn bolt handle to right and down into locked position in receiver. Tighten bolt stop screw. Gun is now fully assembled.


TO LOAD MAGAZINE:—Rotate bolt handle upward, then pull bolt handle back until carrier is in upward position. Turn gun with trigger guard up. Insert shells into magazine which holds five shells. To load sixth shell, turn gun to shooting position, insert front end of shell in ejection port and slide forward until it drops into carrier.

TO LOAD BARREL:—With Safety on "safe" position (with "S" showing) and loaded shell in carrier push bolt handle forward and lock bolt. Gun is now loaded and ready to fire.

TO REPEAT:—Rotate bolt handle upward and pull to rear. This extracts fired shell from barrel. Push bolt handle forward and downward, locking bolt. Gun is ready to fire.

PLUGGING MAGAZINE FOR 3 SHOTS:—Remove magazine band screw. Slide magazine band forward. Remove magazine cap being careful to hold back magazine spring which is under tension. Insert wooden plug and reassemble. This reduces magazine capacity to only 2 shells and one shell in barrel, allows 3 shells in gun.

TO TAKEDOWN GUN:—Unscrew takedown screw, grasp magazine tube and barrel and lift upward and to rear disengaging from stock. To reassemble fit receiver into bedding points in stock with trigger projecting through stock into trigger guard. Securely tighten takedown screw into receiver. Check takedown screw after heavy firing to be sure it is ALWAYS TIGHTLY assembled.



LIST OF PARTS AND ASSEMBLIES FOR

J. C. HIGGINS BOLT ACTION SHOTGUN

MODEL NUMBERS

583.14

583.15

583.16

This is the Model Number of your Bolt Action Shotgun. It will be found on the left side of barrel, just forward of receiver. Always mention this Model Number when communicating with us regarding the Bolt Action Shotgun or when ordering parts.

HOW TO ORDER REPAIR PARTS

All parts listed herein may be ordered through any Sears retail or mail order store. In ordering parts by mail from the mail order store which serves the territory in which you live, always be sure to follow instructions below. Save this list—it is valuable.

WHEN ORDERING REPAIR PARTS AND/OR ASSEMBLIES

Please specify Model No., Part No. and Part Name. When ordering barrels be sure to identify as to type of choke required. All parts identified with an asterisk (*) must be fitted to the gun by gunsmiths in the Sears mail order houses or by qualified gunsmiths.

(PRICES FURNISHED ON REQUEST)

Ref.	Part		Ref.	Part	
	Number	PART NAME	No	Number	PART NAME
110.	114111001	* *************************************	- 110	210022002	- 11414 11114141
1	200	Barrel (specify choke desired)	4	204	Bolt Handle Aligning Plunger
2	201 MA	*Bolt Body Assembly			Spring
_		(Composed of:	5	203	Bolt Handle Aligning Phinger
		201 Bolt Body	6	210MA	*Bolt Head & Stud Assembly
		202 Bolt Handle	_	2101.111	(Composed of:
		223 Firing Pin			205 Bolt Head
		224 Firing Pin Head			
			-7	206	210 Carrier Operating Stud)
		225 Firing Pin Head Cross Pin	7	206	Bolt Head Retaining Pin
		226 Firing Pin Head Lock Pin	8		Bolt Stop Screw
		227 Firing Pin Spring	9	208AMS	
		228 Firing Pin Spring			(Composed of:
		Retaining Sleeve			208AM Carrier & Trunnion
		229 Firing Pin Spring Retain-			Assembly
		ing Sleeve Stop Ring)			215 Cartridge Stop Pin
3	201M	Bolt Body and Bolt Head			217 Combination Cartridge
		Assembly			Stop Spring
		(Composed of:			216 Combination Cartridge
		201MA Bolt Body Assembly			Stop & Lifter)
		203 Bolt Handle Aligning	10	209	Carrier Housing.
		Plunger	11	211	Carrier Pin
		204 Bolt Handle Aligning	12	212	Carrier Plunger
		Plunger Spring	13	213	Carrier Plunger Spring
		210MA Bolt Head and	14	218	
		Stud Assembly	15	219	Ejector
		219 Extractor, Right Hand	16	220	Extractor, Right Hand
		220 Extractor, Left Hand			Extractor, Left Hand
			17	221	Extractor Plunger
		221 Extractor Plunger	18	222	Extractor Spring
		222 Extractor Spring	19	223	Firing Pin
		206 Bolt Head Retaining Pin)	20	224	Firing Pin Head

Ref. I No. N	Part Vumber	PART NAME	Ref. Part No. Number	PART NAME				
22 2 23 2 24 2 25 2 26 2 27 2 28 2 30 2 31 2 33 2 34 2 35 2	225 226 227 228 229 230 231 232 233 234 238 336 234 238 244 244 244 244 244 244 244 244 244 24	Firing Pin Head Cross Pin Firing Pin Head Lock Pin Firing Pin Spring. Firing Pin Spring Retaining Sleeve Firing Pin Spring Retaining Sleeve Stop Ring Front Sight. Magazine Front Band. Magazine Follower. Magazine Follower. Magazine Front Band Binding Screw. Magazine Spring. Recoil Pad Assembly. (Composed of: 241 Recoil Pad 258 Recoil Pad Insert) Recoil Pad Screw. Safety. Safety Spring. Safety Screw. Butt Stock.	41 246 42 247 43 249 44 250 45 251 46 252 47 253 48 254 49 255 50 256 51 260 52 261 53 257	Stock Assembly				